

NETIO PDU settings



NETIO PDU's (Power Distribution Units) are network-based power sockets. You can read more about the products on their website: <https://www.netio-products.com>

NETIO products have a built-in web UI for initial settings, such as:

- IP address
- API protocol
- Username and password

Access web UI

To access the web UI, you simply open a webbrowser and enter the PDU's IP address.

If you don't know the IP address, you can use the NETIO Discover app (for Windows) to discover it on the network. You can download Discover app for free here: <https://www.netio-products.com/en/software/netio-discover>

Settings

To have correct control from SKAARHOJ panels (this means both 'read' and 'write') you must use these specific settings:

1. In the webbased UI goto the '**M2M API Protocols**' page.

2. Select '**JSON API**' tab
3. Enable JSON API - must be ON
4. Enable Read-Write - must be ON
5. Enter desired Username and password (typically the same as you use to login to web UI)
6. Click 'Save Changes'

PowerPDU 8QS 2025-01-06 15:47:00 admin [Sign out](#)

Support 1

M2M API Protocols

JSON API

☒ Enable JSON API **must be ON**

Port:

☒ Enable READ-ONLY

Username:

Password:

☒ Enable READ-WRITE **must be ON**

Username:

Password:

☒ Save Changes **save changes**

Test JSON API:

Open JSON API file (read password required)
<http://192.168.10.253/netio.json>

Download example JSON API file:

- [Set output 1 to ON](#)
- [Set output 1 to OFF](#)
- [Toggle output 1](#)

[Product manual](#) [NETIO products a.s.](#) 3.1.6 - 1.47(1.47) - 0 SN: 24A42C39A413 (cfa2198)

Revision #2

Created 8 January 2025 07:58:56 by Kenneth Kikkenborg

Updated 8 January 2025 08:30:40 by Kenneth Kikkenborg