



Transition Types

The Transition Types constant set is used with the Panasonic Kairos curated configuration to set the 4 available transitions type buttons.



| Column | Description |
|------------------|---|
| Order | Allows for quick rearranging of channel order. Right clicking on order will allow for deleting the row. |
| Mute | Allows for removing access to a specific channel or to leave a blank spot on the panel |
| Transition Index | Sets the transition type based on order available in the Kairos Creator, see chart below. |
| Alternate Label | Customizable name to appear on the displays. Character limit is determined by size of display and can vary. |

There are 82 total defined transitions available

| | | | | | | | | |
|------------------------|-----------------------------|-------------------------------|---|-----------------------------|----------------------------|------------------------|---------------------------------|-------------------------------|
| 0 - Blank | 10- Wipe Box Bottom Right | 20- Barn Door Vertical | 30- PW 2 Blade Horizontal | 40- Wipe Fan Center Top | 50-W Swp Par Vertical | 60- windshield | 70- Rotate Top Right | 80- Squeeze Vertical Center |
| 1 - Mix | 11- Wipe Box Bottom Left | 21- Barn Door Horizontal | 31- PW 4 Blade | 41- WipeFan Center Right | 51- W Swp Par Diagonal | 61- Wipe Snake | 71- Rotate Bottom Right | 81- Squeeze Horizontal Center |
| 2 - Mix via Black | 12- WipeBox Top Center | 22- Barn Door Diagonal Bottom | 32- Swipe Clockwise Top | 42- Wipe Fan Top | 52- W Swp Opp Vertical | 62- Wipe Spiral | 72- Rotate Top Left Reverse | 82- Zoom |
| 3 - Mix Via White | 13- Wipe Box Right Center | 23- Barn Door Diagonal Top | 33- Swipe Clockwise Right | 43- Wipe Fan Right | 53- W Swp Opp Horizontal | 63- Scale | 73- Rotate Bottom Left Reverse | |
| 4 -Wipe Left | 14- Wipe Box Bottom Center | 24- Wipe Circle | 34- Swipe Clockwise Bottom | 44- Wipe Fan Bottom | 54- W Swp Diag Top Left | 64- Push Left | 74- Rotate Top Right Reverse | |
| 5 - Wipe Right | 15 - Wipe Box Left Center | 25- Wipe Star 4 | 35- Swipe Clockwise Left | 45- Wipe Fan Left | 55- W Swp Diag Bottom Left | 65- Push Right | 75- Rotate Bottom Right Reverse | |
| 6 - Wipe Top | 16- Wipe 4 Box In | 26- Wipe Star 5 | 36- Swipe clockwise Top Left | 46- Wipe Fan Out Vertical | 56- Saloon Door Top | 66- Push Up | 76- Squeeze Left | |
| 7- Wipe Bottom | 17- Wipe 4 Box Out | 27- Wipe Star 6 | 37- Swipe Counter clockwise Bottom Left | 47- Wipe Fan Out Horizontal | 57- Saloon Door Left | 67- Push Down | 77- Squeeze Right | |
| 8 - Wipe Box Top Left | 18- Wipe Diagonal Top Left | 28- Wipe Clock | 38- Swipe Clockwise Bottom Right | 48- Wipe Fan In Vertical | 58- Saloon Door Bottom | 68- Rotate Top Left | 78- Squeeze Top | |
| 9 - Wipe Box Top Right | 19- Wipe Diagonal Top Right | 29- PW 2 Blade Vertical | 39- Swipe Counter Clockwise Top Right | 49- Wipe Fan In Horizontal | 59- Saloon Door Right | 69- Rotate Bottom Left | 79- Squeeze Bottom | |

Revision #1

Created 12 August 2022 12:27:27 by Heather Pedersen

Updated 17 August 2022 09:14:47 by Heather Pedersen