

Using One Blue Pill Panel as the Main Unit


To set up multiple Blue Pill Inside units to work in a group together, it is necessary to change some settings in the connected panels to allow them to be controlled by the main Blue Pill panel.

The connected unit needs the following changes:

1. Stop Reactor



2. Disable Auto-Start



3. Enable Listen on Port in Hardware Manager

Package > hardware-manager, Version: 0.0.9-pre10

● Running Restart Auto start

Connection

ListenOnSocket

☒

If hardware-manager should listen on a local socket, this will make it possible for the local reactor to connect natively (recommended)

ListenOnPort

☒

If hardware-manager should listen for incoming connections on a port

DisplayIP

☒

If IP address should be displayed

Port

9923

The external port to listen on using raw panel binary protocol

Reset to defaults Save and restart

4. Save and restart

5. Add as normal panel to the main BP/BPI

Please Note, turning off Reactor will limit the page selections to Package and Settings. All other pages are part of the Reactor firmware package.

Revision #6

Created 18 March 2022 09:31:44 by Heather Pedersen

Updated 24 October 2023 12:01:18 by Heather Pedersen