

What are Configuration Classes ?

When getting started in Reactor you most likely want to get your configuration done fast, so you can focus on your valuable production. But to do so you need to setup you devices, likely multiple of them, from different manufacturers or of different models.

To make this process easier and to make combining cameras a breeze we have created the concept of **configuration classes**. The different configuration classes basically suggest a group of panels, and define a standardized way of setting up default configurations. With all device cores in reactor supporting this "format" you can now easily combine different devices on a panel, without having to worry about assigning individual actions for these different devices to your controller.

Reactor will cleverly combine the default configuration classes to give you **the best experience out of the box!**

See what Configuration Class your Panel belongs to here:

[Pro Class Configurations](#)

[Standard Class Configurations](#)

[Light Class Configurations](#)

[Quick Class Configurations](#)

[Switcher Class Congratulations](#)

[Audio Class Congratulations](#)

Revision #11

Created 10 March 2022 10:08:09 by Lukas Bachschwell

Updated 1 November 2023 08:26:40 by Samuel Jakobsen