

Arri Camera settings

The SKAARHOJ Arri device core can control Arri Cameras over CAP and older cameras over SSCP. Please make sure to adjust the settings in the camera(s).

Arri Amira & Arri Alexa Mini

- Enable CAP in the menu
- Use Arri Multicam Look file, otherwise you might not be able to change color parameters
- Enable Multicam Mode, set SSCP IP to the IP of your SKAARHOJ Panel

Arri Alexa Mini LF

This camera only supports CAP, which makes setup easier

- Enable CAP in the menu, check the set password (default: arri)
- Use Arri Multicam Look file, otherwise you might not be able to change color parameters
- Enable Multicam Mode, set SSCP IP to the IP of your SKAARHOJ Panel

Arri Alexa35

This camera only supports CAP, which makes setup easier

- Enable CAP in the menu, check the set password (default: arri)
- Make sure your camera is fully up to date and has the Arri Multicam License
- Turn on Live Painting in the menu
- Duplicate the default Look File, otherwise you might not be able to change color parameters

Revision #3

Created 24 April 2024 09:22:49 by Lukas Bachschwell

Updated 13 May 2024 07:52:32 by Kenneth Kikkenborg