

# Arri Camera settings

The SKAARHOJ Arri device core can control Arri Cameras over CAP and older cameras over SSCP. Please make sure to adjust the settings in the camera(s).

## Arri Amira & Arri Alexa Mini

- Enable CAP in the menu
- Use Arri Multicam Look file, otherwise you might not be able to change color parameters
- Enable Multicam Mode, set SSCP IP to the IP of your SKAARHOJ Panel

## Arri Alexa Mini LF

This camera only supports CAP, which makes setup easier

- Enable CAP in the menu, check the set password (default: arri)
- Use Arri Multicam Look file, otherwise you might not be able to change color parameters
- Enable Multicam Mode, set SSCP IP to the IP of your SKAARHOJ Panel

## Arri Alexa35

This camera only supports CAP, which makes setup easier

- Enable CAP in the menu, check the set password (default: arri)
- Make sure your camera is fully up to date and has the Arri Multicam License
- Turn on Live Painting in the menu
- Duplicate the default Look File, otherwise you might not be able to change color parameters

---

Revision #3

Created 24 April 2024 09:22:49 by Lukas Bachschwell

Updated 13 May 2024 07:52:32 by Kenneth Kikkenborg