

Canon EOS C500 and EOS C300 (Canon-XC)

The currently recommended Core version for EOS C500 and EOS C300 is depended on the firmware version your cameras is on.

This matrix should explain what Canon-XC core version as appropriate for your camera:

| Canon XC Core Version | Device Core v0.1.9 or below | Device Core v0.2.0-Pre3 or above |
|-------------------------|----------------------------------|----------------------------------|
| Canon EOS C300 Mark III | Canon Firmware v1.0.3.1 or below | Canon Firmware v1.0.4.1 or above |
| Canon EOS C500 Mark II | Canon Firmware v1.0.5.1 or below | Canon Firmware v1.0.6.1 or above |

If you do not have the newest firmware and want to update your cameras, then you can find the firmware for both models on the Canon USA website by following these links:

[EOS C300 Mark iii](#)

[EOS C500 Mark ii](#)

Revision #3

Created 14 October 2022 12:07:43 by Andreas Hauge Thomsen

Updated 13 May 2024 07:52:32 by Christoffer Thinggaard