

Panasonic Lumix

Tether


The Panasonic Lumix only allows 1 network connected client at a time. This means it is not possible to use both Panasonic's Tether interface and a Skaarhoj panel simultaneously.

Password

Connectivity to the Panasonic Lumix requires a password. Due to the way the password is usually set in the Lumix, it can be necessary to connect with the Lumix set to the default password:

FGHIJ67890

The password needs to be entered in the Device Details section for each connected Lumix camera.



Missing IP
Development status: alpha

BS1H

Active

IP
IP address of the camera

Port
Port number of the camera (Default: 15740)

Password
Password for the camera

Name

Device Id

Model Id

Description

Delete Save

Connectivity Issues

If you encounter connection issues despite all settings appearing correct, we advise performing a factory reset on the camera and using the default password. Crucially, after resetting, avoid connecting the camera with the Lumix Tether application, as it might lock in the camera somehow and thereby prevent the SKAARHOJ device from connecting. The exact cause is unclear, but this solution has been effective for other users.

Revision #4

Created 10 August 2022 08:10:35 by Heather Pedersen

Updated 27 April 2026 10:55:50 by Kasper