

Quick Start Guide - Blue Pill

Get started with your Blue Pill Inside product.

- [Quick Start Guide - Blue Pill Inside products](#)
- [Quick Start Guide - Blue Pill Server](#)

Quick Start Guide - Blue Pill

Inside products

Follow 4 steps and get started



1. Connect

Simply plug in your network connected cat 5 (or better) POE cable to your SKAARHOJ Blue Pill Inside device for internet access.

2. Go to IP address

On your SKAARHOJ device's screen an IP address will pop up.* Type the IP into your web browser.



Quick Start Guide - Blue Pill Server

Follow 5 steps and get started

1. Connect

Simply plug in your network connected cat 5 (or better) POE cable to your Blue Pill device for internet access.

2. Go to IP address

On your Blue Pill Server screen an IP address will pop up.* Type the IP into your web browser. Default credentials are:
User: admin Password: skaarhoj

* Requires DHCP.



3 Add Panel
Welcome to Reactor!

