

# Quick Start Guide - Blue Pill

Get started with your Blue Pill Inside product.

- [Quick Start Guide - Blue Pill Inside products](#)
- [Quick Start Guide - Blue Pill Server](#)

# Quick Start Guide - Blue Pill

## Inside products

# Follow 4 steps and get started



## 1. Connect

Simply plug in your network connected cat 5 (or better) POE cable to your SKAARHOJ Blue Pill Inside device for internet access.

## 2. Go to IP address

On your SKAARHOJ device's screen an IP address will pop up.\* Type the IP into your web browser.





# Quick Start Guide - Blue Pill Server

# Follow 5 steps and get started

## 1. Connect

Simply plug in your network connected cat 5 (or better) POE cable to your Blue Pill device for internet access.

## 2. Go to IP address

On your Blue Pill Server screen an IP address will pop up.\* Type the IP into your web browser. Default credentials are:  
User: admin Password: skaarhoj

\* Requires DHCP.



## 3 Add Panel

Welcome to Reactor!

