

Quick Start Guide - Blue Pill Server

Follow 5 steps and get started

1. Connect

Simply plug in your network connected cat 5 (or better) POE cable to your Blue Pill device for internet access.

2. Go to IP address


On your Blue Pill Server screen an IP address will pop up.* Type the IP into your web browser. Default credentials are:
User: admin Password: skaarhoj

* Requires DHCP.



3 Add Panel

Welcome to Reactor!



Revision #1

Created 17 November 2022 12:24:35 by Louise

Updated 17 November 2022 12:40:54 by Louise