



# Projects

Projects are the unit that have a title, description and references to a panel collection, a device collection and a configuration. This design provides the flexibility to use the same set of SKAARHOJ panels but quickly change to another location of devices with other IP addresses for example. Or keep the same devices and panels, but run a different configuration serving a different user group of operators.




When a Blue Pill ships it has a default configuration is as below. It is set in simple view with only the basic information available.




Unlike UniSketch where a change of configuration and device cores needed an online connection to SKAARHOJ server, on Blue Pill everything is stored locally in Reactor. Only software upgrades or installations of non-existing device cores and applications need communication with the server.

## Creating Projects


To create a new project click Manage Project within Reactor Home.



Select Create new project on the projects pop up.



There are two main parts of the project: Name and Description.



Name	Customizable project name
Description	Option description of the project for reference

Advanced brings with it additional project options.

## Project Details



Show Advanced



Title:

Manual

Description:

Type the descriptions of the project

Mode:

Normal  Devices only  Demo  Mono Panel

Filename:

Manual

Panel Collection:

Manual Version: latest



New

Device Collection:

Manual Version: latest



New

Configuration:

Manual Version: latest



New

Activate

Delete

Duplicate

Export


Save

<b>Mode</b>	<ol style="list-style-type: none"><li>1. Normal for normal operation</li><li>2. Devices only for when a Blue Pill will only be used to run device cores and not panels</li><li>3. Demo runs a color slash across the connected controllers</li><li>4. Mono panel for working with multiple panels as one in raw panel mode</li></ol>
<b>File Name</b>	Master name for the file when making new collection, configuration, and exports
<b>Panel Collection</b>	Allows for the sharing of panel collections across projects on a Blue Pill
<b>Device Collection</b>	Allows for the sharing of devices collections across projects on a Blue Pill


<b>Configuration</b>	Allows for the selection of a specific layer files in the configuration across projects on a Blue Pill
<b>Activate</b>	Makes the project the current active project. The project needs to be active to use or work with it
<b>Delete</b>	Deletes the project
<b>Duplicate</b>	Duplicates the projects
<b>Export</b>	Allows for the exporting of the projects

## Import/Export Projects


It is also possible to import and export projects to more easily share between different Blue Pill devices. This option is available next to create new projects in the Manage Projects pop up. You can also right-click a project name to open a context menu, where you can select 'Export project'.



Import allows for a simple file upload. With the option to have the file name become the project name.




Export allows for the selection of what to include or exclude from the file. This can be the panels, devices, or configuration. This is specific project based and not for the entire Blue Pill.



## Editing Projects

To change the details of the project click the project name within Reactor Home



Or within any of the project detail boxes on the projects pop up.

Project Title	Description	Special Notice	Status
bluepill	Congratulations with your new bluepill! It's going to be amazing from here...	Advanced settings used	Active

It is then possible to customize the name and description of the project. Press Save.

Project Details  Show Advanced

Title: bluepill

Description: Congratulations with your new bluepill!!! It's going to be amazing from here...

Save

Enabling Advanced view brings about extra options for editing the project outside of the basic details, the same as would be seen when creating a new project.

### Layer Configuration Version Look Up

In the layer configuration section, it is possible to access autosaved versions of the configurations. This is useful when a lot of changes have been made and it is necessary to roll things back a little.

When in the Configuration section, click on the little clock symbol next to the layer to see previous versions.

**Project Details** Show Advanced

Title:

Description:

Mode:  Command Dispatch  Demo  Mono Panel

Filename:

Panel Collection:  New

Device Collection:  New

Configuration:  New

Duplicate Export Save

- default Version: latest
- SKAARHOJ.Controllers.ARRI.Official Version: latest
- SKAARHOJ.Controllers.AirFly.ATEM.classic Version: latest
- SKAARHOJ.Controllers.AirFly.vMix.basic Version: latest
- SKAARHOJ.Controllers.LiveFly+XPoint24.ATEM.classic Version: latest
- SKAARHOJ.Controllers.LiveFly.ATEM.Classic Version: latest
- SKAARHOJ.Controllers.LiveFly.Sony.basic Version: latest
- SKAARHOJ.Controllers.LiveFly.vMix.basic Version: latest
- SKAARHOJ.Controllers.MicroFly.ATEM.basic Version: latest
- SKAARHOJ.Controllers.Minifly.ATEM.basic Version: latest
- SKAARHOJ.Controllers.QuickPad.ATEM.basic Version: latest
- SKAARHOJ.Controllers.RackFlyDuo.Aja-Kumo Version: latest
- SKAARHOJ.Controllers.RackFlyDuo.Optocore.Generic Version: latest
- SKAARHOJ.Controllers.RackFlyTrio.Aja-Kumo Version: latest
- SKAARHOJ.Controllers.RackFlyTrio.Optocore.Generic Version: latest
- SKAARHOJ.Controllers.RackFlyUno.Aja-Kumo Version: latest
- SKAARHOJ.Controllers.RackFlyUno.Netio Version: latest
- SKAARHOJ.Controllers.RackFlyUno.Optocore.Generic Version: latest

Import/Export

Available versions are: every change from the last 24 hours and as 1 file per day for 10 days.

It is also possible to add tags or comments to individual versions. When a tag or comment is added to the version, it will no longer be deleted based on the default time scale and will persist.

Version Tags	Created
  latest Tags: No tags	01/07/2022, 12:04:48 PM
  Tags: No tags	01/03/2022, 03:26:34 PM
  Tags: No tags	12/03/2021, 11:58:51 PM

Rows per page: 15 1-3 of 3

Revision #8

Created 7 October 2022 07:19:53 by Heather Pedersen

Updated 7 July 2025 12:45:36 by Heather Pedersen