

# Panasonic Lumix

## **Tether**


The Panasonic Lumix only allows 1 network connected client at a time. This means it is not possible to use both Panasonic's Tether interface and a Skaarhoj panel simultaneously.

## **Password**

Connectivity to the Panasonic Lumix requires a password. Due to the way the password is usually set in the Lumix, it can be necessary to connect with the Lumix set to the default password:

**FGHIJ67890**

The password needs to be entered in the Device Details section for each connected Lumix camera.




Missing IP  
Development status: alpha

**BS1H** ✕

Active


IP   
IP address of the camera

Port   
Port number of the camera (Default: 15740)

Password    
Password for the camera

Name

Device Id

Model Id  

Description

## Connectivity Issues

If you encounter connection issues despite all settings appearing correct, we advise performing a factory reset on the camera and using the default password. Crucially, after resetting, avoid connecting the camera with the Lumix Tether application, as it might lock in the camera somehow and thereby prevent the SKAARHOJ device from connecting. The exact cause is unclear, but this solution has been effective for other users.

Revision #4

Created 10 August 2022 08:10:35 by Heather Pedersen

Updated 22 June 2026 08:00:26 by Kasper