


Camera Selector Settings Table

To complete the process, the Tally Index number needs to be set in the Camera Select settings table. This number is the one associated with input number on the switching panel. Please note that sometimes the first input might have an internal number of 0, if you find the preview/program to be offset, try setting input 1 as 0.



Revision #2

Created 25 March 2022 14:44:53 by Heather Pedersen

Updated 26 June 2025 12:22:25 by Heather Pedersen